

DATA SHEET

OXY-LC

Oxygen Sensor Interface Board



- Provides the electronics necessary to power and control SST's range of zirconium dioxide (ZrO₂) sensors
- Built in pressure sensor for barometric pressure compensation
- Interface mounted screw terminals for easy wiring with reverse voltage and transient overvoltage

















Analogue Output





Response **Time**







- Adaptive software filtering provides a fast sensor response coupled with a stable oxygen output
- High accuracy linear output

TECHNICAL SPECIFICATIONS

Supply voltage

RS485 variant: $8-28V_{DC}$ Analogue variants: 20-28V_{DC}

Supply current 600mA max. at $24V_{DC}$

1.2A max. at 12V_{DC}

Digital output RS485 (Modbus RTU)

or

4-20mA: load 600Ω max Analogue output

> 0— $10V_{DC}$; load $10k\Omega$ min or

Temperature limits

-40°C to +85°C Storage: Operating: -30°C to +70°C

Operating pressure limits¹ 260—1260mbar absolute



Oxygen range (analogue output)

 0.1^2 —25% O_2

 $0.1^2 - 100\% O_2$ $0.1^2 - 100\% O_2$

Oxygen range (Modbus RTU)

Accuracy after calibration³ Repeatability after calibration 0.5% O₂ 0.5% O₂

Output resolution

0.01% O₂

Response time (step 10-90%)

4s

60s

Fast response sensor connected: Standard response sensor connected:

15s 5—10mins

Initial warm up time (till stable output) Output inactive start up delay (heater warm up)

From OFF to ON mode:

From Standby to ON mode (RS485 only): 20s



- Sensor and interface for correct barometric pressure compensation.
- Prolonged operation below 0.1% O₂ can damage the sensing element.
 - Analogue output variants accuracy stated is valid when calibrated at the default calibration value. RS485 variant accuracy stated is valid when calibrated at the default 20.7% O_2 over the range 0.1 to 25% O_2 . For maximum accuracy above 25% O_2 the interface and sensor should be calibrated to full scale of the required range using certified gas.

Apollosense Ltd

Adress: Room 712, Huaneng Building, Shennan Zhong Road, Shenzhen 518031,

Tel: (86-755) 83680810 83680820 83680830 83680860 Fax: (86-755) 83680866

Adress: Unit 1502, Hollywood Plaza, 610 Nathan Road, Mong Kok, Kln., H.K.


Tel: (852) 2737 0903


Fax: (852) 2737 0938 Email: sales@apollounion.com



OUTLINE DRAWING AND MOUNTING INFORMATION

All dimensions shown in mm. Tolerances = ±1mm.





Apollosense Ltd

Tel: (86-755) 83680810 83680820 83680830 83680860 Fax: (86-755) 83680866 Hong Kong:

Adress: Unit 1502, Hollywood Plaza, 610 Nathan Road, Mong Kok, Kln., H.K.


Tel: (852) 2737 0903 Fax: (852) 2737 0938 Email: sales@apollounion.com



ELECTRICAL INTERFACE



Always handle the interface board using the correct ESD handling precautions.



Pin	Assignment			
1	Sensor Heater + (1)			
2	Sensor Heater 0V _{DC} (2)			
3	Sensor Pump			
4	Sensor Common			
5	Sensor Sense			
6	8—28V _{DC}			
7	0V _{DC}			
8	RS485 A (+)			
9	RS485 B (-)			

Comm. Setting	Default Value		
Address	1		
Baudrate	9600		
Parity	None		
Stopbits	1		

Pin	Assignment			
1	Sensor Heater + (1)			
2	Sensor Heater 0V _{DC} (2)			
3	Sensor Pump			
4	Sensor Common			
5	Sensor Sense			
6	20—28V _{DC}			
7	0V _{DC}			
8	4—20mA or 0—10V _{DC}			
9	Calibrate IN/PWM OUT			

O ₂ %	Output Value				
	0—10V _{DC}		4—20%mA		
	0.1—25% O ₂	0.1—100% O ₂	0.1—25% O ₂	0.1—100% O ₂	
20.7%	8.28V _{DC}	2.07V _{DC}	17.25mA	7.34mA	
100%	-	10V _{DC}	1	20mA	
90%	-	9.0V _{DC}	1	18.4mA	
25%	10V _{DC}	2.5V _{DC}	20mA	8mA	
5%	2.0V _{DC}	0.5V _{DC}	7.2mA	4.8mA	
0.1%	0.04V _{DC}	0.01V _{DC}	4.06mA	4.02mA	

Notes:

- Output pins 1 through 5, refer to appropriate SST oxygen sensor datasheet for wiring/pin designations. 1.
- 2. Every SST oxygen sensor has two heater connections which should be connected to pins 1 & 2 of the OXY-LC; the heater coil has no polarity. However when connecting to a sensor where the sensor housing is one of the heater connections, pin 2 of the OXY-LC should be connected to the housing.

Apollosense Ltd

Shenzhen:

Fax: (86-755) 83680866

Adress: Room 712, Huaneng Building, Shennan Zhong Road, Shenzhen 518031,

China

Tel: (86-755) 83680810 83680820 83680830 83680860

Hong Kong: Adress: Unit 1502, Hollywood Plaza, 610 Nathan Road, Mong Kok, Kln., H.K.

Tel: (852) 2737 0903 Fax: (852) 2737 0938 Email: sales@apollounion.com






Generate your specific part number using the convention shown below. Use only those letters and numbers that correspond to the options you require - omit those you do not.

Digital Variant

OXY-LC-485

Analogue Variants





Do not exceed maximum ratings and ensure sensor(s) are operated in accordance with their requirements.

Carefully follow all wiring instructions. Incorrect wiring can cause permanent damage to the device.

Zirconium dioxide sensors are damaged by the presence of silicone. Vapours (organic silicone compounds) from RTV rubbers and sealants are known to poison oxygen sensors and MUST be avoided. Do NOT use chemical cleaning agents.

Failure to comply with these instructions may result in product damage.

1 INFORMATION

As customer applications are outside of SST Sensing Ltd.'s control, the information provided is given without legal responsibility. Customers should test under their own conditions to ensure that the equipment is suitable for their intended application.

For detailed information on the sensor operation refer to application note AN0043 Operating Principle and Construction of Zirconium Dioxide Oxygen Sensors.

General Note: SST Sensing Ltd. reserves the right to make changes to product specifications without notice or liability. All information is subject to SST Sensing Ltd.'s own data and considered accurate at time of going to print.

DS-0058 REV 6

© 2016 SST SENSING LTD.



Apollosense Ltd

Shenzhen:

Adress: Room 712, Huaneng Building, Shennan Zhong Road, Shenzhen 518031,

China

Tel: (86-755) 83680810 83680820 83680830 83680860

Fax: (86-755) 83680866

Hong Kong:

Adress: Unit 1502, Hollywood Plaza, 610 Nathan Road, Mong Kok, Kln., H.K.

Tel: (852) 2737 0903 Fax: (852) 2737 0938 Email: sales@apollounion.com